

T-2713-T Spindle Bushing Driver

INSTRUCTIONS

1. Place new bushing in top hole of spindle body.
2. Insert driver in bushing and drive down with hammer until seated.
3. Turn spindle upside down, and place “BUTTON” in bushing hole. Place new bushing in bottom of spindle and drive with hammer until seated.
4. Spindle must be reamed for accurate fit.
5. If bushing must be faced off, remove material from bottom bushing.