

A-11558 POP OUT TAG

This authentic U.S.A. made precurved data tag is used on early style popout cables, often called banana pop-out. Care is required to assemble drive screws in the proper position particularly after painting. Position the tag and scribe the two hole outlines. Prick punch the center of the outlines. Carefully drill the holes using a No. 44 (.088) drill. Limit drilling depth to 3/16". Remove the protective cover using a knife point near the rivet holes. Position and tap in the drive rivets.

Note: Position along the straight section and to read from the right side.