

## **A-9700-W Choke Cable Assembly Instructions**

*Works on all Model A gas tanks except early 1928.*

1. Remove old choke rod and grommet from bracket on the gas tank. Clean hole in bracket with a round file or sandpaper .
2. Slide the adapter and cable through the bracket and test fit to see that it will clear the lower radius of the gas tank. Many brackets have been bent and modified from years of use. It may be necessary to enlarge the hole by lightly filing it with a round file. Sometimes it is also necessary to remove some material from the base of the adapter to clear. Use a flat file and file a flat spot on the adapter until it fits.  
Do not file or remove any of the threaded base.
3. Once the adapter and cable are fitted into the tank bracket, thread on the nut and tighten it down. Route the flexible cable over the gas line on 1928-mid 31 style cars and through the hole on the firewall. On Late 1931's the cable will go directly through the hole in the firewall. Make sure there are no hard bends in the cable. Attach the cable to the choke bracket/holder on the carburetor.
4. To trim the excess length off the cable pull the serrated round knob inside the car out about 6 to 8 inches. Use a pair of diagonal pliers and cut the inner and outer cable just past the bracket on the carburetor. Now push the inner cable back in and attach it to the choke on the carburetor .