

T-7853-2627N8 & T-7853-2627C8 MOUNTING INSTRUCTIONS

The upper and lower windshield frames are attached to the windshield stanchions with studs and chrome plated wing nuts. The mirror mounts to the lower windshield mounting stud. The original stud is too short to accommodate the thickness of the mounting arm so the stud must be changed to the longer stud that is supplied with your arm. Once you have changed the original stud to the longer stud, slide the mirror arm in place with the horizon part of the arm above the stud and secure with the original chrome wing nut.