

A-8274 HOT WATER HEATER HOOK -UP KIT

1. Drain coolant from system.
2. Remove upper radiator hose.
3. Cut a large enough section out of your top radiator hose to mount the short pipe using the authentic style hose clamps included in your kit. This pipe should be centered between the outlet on the head and the radiator inlet. The large coupling in the pipe is for the thermostat probe, and the smaller is for your heater hose fitting to attach. Position the pipe according to how or where you want to run your heater hose and temperature probe.
4. If you are using a thermostat in your car, It should now be moved to the outlet end of this pipe. (end toward the radiator)
5. Wrap some teflon tape around the threads of the temperature probe fitting and install in the large hole.
6. Locate the special brass elbow fitting that has a copper elbow fitting soldered to it. The purpose of the copper fitting being soldered to this piece is to capture water as it is being pumped to the top of the radiator and force it through your heater. Wrap some teflon tape around the male threads of this fitting and thread it into the smaller hole of the pipe. Keep in mind that the open end of the copper elbow that is inside the pipe needs to face towards the engine. When installed and tightened, the hose hook up of this fitting should be pointing towards the motor.
7. Remove the lower water pipe and reinstall the drain petcock in the new pipe with some teflon tape.
8. Wrap some teflon tape around the male threads of the remaining brass elbow fitting and install it in the larger hole of the lower pipe. When tight, you will want the hose hook up to be facing the firewall.
9. Everything that came with your kit should now be installed. Due to various heater locations, we do not include hose or hose clamps for attaching this kit to your heater. Heater hose and clamps can be purchased from your local auto parts store.

Your kit should include the following:

SHORT UPPER PIPE

LONG LOWER PIPE

2 LARGE HOSE CLAMPS

1 BRASS ELBOW FITTING

1 BRASS ELBOW FITTING -W- COPPER ELBOW SOLDERED