

T-3025 When installing new connecting rod bolts, always check clearance between the bolt heads and the camshaft. In certain cases, the tip of the bolt head can come in contact with the cam. If this happens, simply file or grind the bolt head. Normally you will just be tapering the head to make the head skinnier towards the outside edge of the connecting rod.