

A-5311 Front Panard Bar

Installation Instructions

1. Remove the left front shock from the frame.
2. Place the large bracket on the frame aligning holes with the holes in the frame, and bolt the shock over the bracket.
3. Remove the back plate from the right front spring shackle. Replace it with the small bracket with the stud facing toward the center of the axle, bolt toward the rear.
4. Install the bar onto the stud and adjust to bolt onto the large bracket. Tighten stud and end bolts.
5. Turn the bar “hand-tight” and lock the jam nuts.

You are finished. Enjoy the safety of better road handling!